

## Manual Oil Exchanger for Automatic Transmissions

manual

- A: Control panel with used oil pressure gauge, taps/phase switches and flowmeters
- **B**: Kit of couplings and hoses for European and Asiatic vehicles (standard included)
- C: SmartPack (12 months of free access to the online Database)
- **D**: 500ml additive injector with protection against operational errors
- E: Automatic hose inversion
- F: 20 liter removable oil containers for new/ used oil
- G: 2 sintered magnetic filters (reusable)
- H: Magnetic litre-counters: Useful for visual control of the levels (used oil, new oil)
- I: Facilitated use of the appliance





## ATF RÈMIN SW Cod. 02.023.57





